


MadBoy[®]

BONEHEAD-206


6" POWERED SPEAKER SYSTEM




USER MANUAL

WWW.MADBOY-AUDIO.COM

Operation notice!



CAUTION
RISK OF SHOCK



CAUTION: To reduce the risk of electric shock, do not remove cover (or back). No user-serviceable parts inside. Only refer servicing to qualified service personnel.

Explanation of Graphical Symbols



The lightning flash & arrowhead symbol, within an equilateral triangle, is intended to alert you to the presence of danger.



The exclamation point within an equilateral triangle is intended to alert you to the presence of important operating and servicing instructions.

WARNING

To reduce the risk of fire or electric shock, do not expose this unit to rain or moisture.

1. **Read Instructions**– All the safety and operating instructions should be read before the appliance is operated.
2. **Retain Instructions**– The safety and operating instructions should be retained for future reference.
3. **Heed Warnings**– All warnings on the appliance and in the operating instructions should be adhered to.
4. **Follow Instructions**– All operating and use instructions should be followed.
5. **Attachments**– Do not use attachments not recommended by the product manufacturer as they may cause hazards.
6. **Water and Moisture**– Do not use this unit near water. For example, near a bathtub or in a wet basement and the like.
7. **Carts and Stands**– The appliance should be used only with a cart or stand that is recommended by the manufacturer.
 - 7A. An appliance and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause an overturn.
8. **Ventilation**– The appliance should be situated so its location does not interfere with its proper



ventilation. For example, the appliance should not be situated on a bed, sofa, rug, or similar surface that may block the ventilation slots.

9. **Heat**– The appliance should be situated away from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
10. **Power Sources**– The appliance should be connected to a power supply only of the type described in the operating instructions or as marked on the appliance.
11. **Grounding or Polarization**– Precautions should be taken so that the grounding or polarization means of an appliance is not defeated.
12. **Power-Cord Protection**– Power-supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the appliance.
13. **Cleaning**– Unplug this unit from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners. Use a damp cloth for cleaning.
14. **Power lines**– An outdoor antenna should be located away from power lines.
15. **Nonuse Periods**– The power cord of the appliance should be unplugged from the outlet when left unused for a long period of time.
16. **Object and Liquid Entry**– Care should be taken so that objects do not fall and liquids are not spilled into the enclosure through openings.
17. **Damage Requiring Service**– The appliance should be serviced by qualified service personnel when:
 - A. The power supply cord or plug has been damaged; or
 - B. Objects have fallen into the appliance; or
 - C. The appliance has been exposed to rain; or
 - D. The appliance does not appear to operate normally or exhibits a marked change in performance; or
 - E. The appliance has been dropped, or the enclosure damaged.
18. **Servicing**– The user should not attempt to service the appliance beyond that described in the operating instructions. All other servicing should be referred to qualified service personnel.

Note:
To CATV system installer's (U.S.A.): This reminder is provided to call the CATV system installer's attention to Article 820-40 of the NEC that provides guidelines for proper grounding and, in particular, specifies that the cable ground shall be connected as close to the point of


For geeks:

- HIGH QUALITY POWERED SPEAKER SYSTEM
- 6,5" WOOFER AND 2" TWEETER
- BUILD-IN 2 x 25W RMS AMPLIFIER
- FREQUENCY RESPONSE: 60Hz – 20kHz
- VOLUME CONTROL
- STEREO RCA LINE INPUT (L/R)
- STEREO RCA LOOP THROUGH (L/R)


Before Getting Started

Please check that the following items are included with your MadBoy BONEHEAD-206 Speaker system:


- 2 BONEHEAD-206 Powered Speakers (1 with amplifier and 1 without)
- 1 RCA to RCA-stereo cable
- 1 Power cord
- 1 Speaker cable (red and black)




BONEHEAD-206 (2)



Power Cord (1)




RCA Audio Cable (1)



Speaker Cable (1)

Getting connected

1. SPEAKER OUTPUT (to connect passive BONEHEAD-206 speaker)
- 1B. SPEAKER INPUT (in rear panel of passive BONEHEAD-206 speaker)
2. AC INPUT (to connect power cord)
3. POWER SWITCH (to turn power on/off)
4. VOLUME (to turn volume level up and down)
5. LINE IN (to connect ie. CD-player, MP3-player etc. with RCA-stereo cable)
6. LINE OUT (to connect ie. active subwoofer with RCA-stereo cable)



Connecting a passive speaker (without amplifier) and power cable.

What you will need

- Another speaker of BONEHEAD-206 without amplifier on it. Speaker included
- Speaker cable (red and black). Cable included.
- Power cable. Cable included.

1. Connect one end of each speaker cable to the speaker output (1)/input(1B) red to red and black to black. (1)
2. Connect the power cable to the AC input, on BONEHEAD-206 rear panel. (2)
3. When cable is inserted to AC input of the BONEHEAD-206, connect another end of the cable to AC-wall outlet.
4. After connecting all necessary cables, players etc. (see page 4) turn power on from power switch. (3)

NOTICE! When connecting cables etc. make sure power is turned off and volume (4) is turned down (in BONEHEAD-206 and ie. amplifier)! This is to avoid any unwanted noise/hazard.


Getting connected continues

Connecting a Mixer/player (Fig. A)

What you will need

- Audio source(DVD, CD, mixer etc.) with Stereo audio output (Left and Right)
- RCA cable (Left(red) and Right(white)). Cable included.

1. Connect one end of each RCA cable to the RCA audio Left and Right outputs on the player/mixer.
2. Connect the other end of each RCA cable to the Left and Right RCA Audio Input jacks on the rear panel of the BONEHEAD-206




Connecting to ie. active subwoofer (ie. MadBoy BOSS-10) (Fig. B)

What you will need

- 1 RCA-RCA cable

1. Connect RCA plug to end of active subwoofer line/audio in.
2. Connect the other end of the RCA cable to Line out on BONEHEAD-206 rear panel.



NOTICE! When connecting BONEHEAD-206 to another device via line out, make sure power is turned off and volume is turned down (in both device ie. amplifier)! This is to avoid any unwanted noise/hazard.

